


Keyless IP Series Access Control
External Powered
12 VDC (Fail Safe) Maglock




Edge Solo Configuration
Under Installer Settings,
Door Parameters,
Set Reader Type to "Card"
Keypad Type to "HID"
Electrical Interface to "Wiegand"

Installer Settings

 Door Parameters	
Reader Type:	Card
Keypad Type:	HID
Electrical Interface:	Wiegand



Keyless IP Series Access Control External Powered 12 VDC (Fail Secure) Strike



Note: Reader may be different depending on system



Edge Solo Configuration Under Installer Settings, Door Parameters, Set Reader Type to "Card" Keypad Type to "HID" Electrical Interface to "Wiegand"

Installer Settings

Door Parameters

Reader Type: Card

Keypad Type: HID

Electrical Interface: Wiegand